HBM1001

Body Massager

Instruction Manual

◆ Please read enclosed Instruction Manual carefully before using.

◆ Keep manual in a safe place for quick easy reference.

Content

- SAFETY • • • • • • • • • • • • • • • P1
- PARTS IDENTIFICATION • • • • P1
- OPERATION • • • • • • • • • • • • P2 - 4
- AFTER USAGE • • • • • • • • • • • P5
- REPAIR SERVICE • • • • • • • • • P5 - 6

SAFETY INFORMATION

- Keep the unit and packaging material away from children.
- Only operate with supplied AC adaptor.
- Do not use if the device or any of its accessories appear to be damaged.
- Keep the unit and AC adaptor away from water or other liquids or other damp surfaces. Never use in bath, shower, sauna, pool, etc.
- Never try to retrieve the device if it falls into water. Disconnect the plug immediately from the electrical outlet.
- Repairs to electrical appliances must only be carried out by qualified persons. Incorrect repairs can lead to considerable danger to the user.
- Switch the device off and disconnect the power supply after every use and before cleaning.
- Follow local regulations regarding the disposal of materials. Contact your local authorities for proper waste disposal in your area.

PARTS IDENTIFICATION

Main Body

Applicators

OPERATION

1. Attach appropriate applicator to the main unit.

Face Roller

Body Roller

2. Connect the unit to the AC adaptor. Before connection, make sure the unit is set to the OFF position.

3. Hold the unit at handle part and apply the unit on the area to be massaged.

Attention:
If using the unit on face, it is recommended to wear a headband or place hair in a ponytail to remove hair from the face to avoid hair from becoming tangled by the unit.



4. Select Power Button for suitable application.

FACE (LOW) setting	Very slow movement, recommended for face.
BODY (HIGH) setting	High speed movement for Body use only.

*NOTE: Do not use BODY setting on FACE.

5. Please refer to the following details when using. A maximum of 5 minutes is recommended per area being treated to avoid over-stimulation.

OPERATION

Safety Protection

When the unit continuously runs for more than 20 minutes, the unit will stop working. This is to avoid the unit from over-heating.

Please power off the unit and let it cool down for 1 hour before using again.

Caution during operation

Attention

- Do not use around the eyes.
- Maximum 5 minutes of treatment in one area, no more than 30 minutes of treatment on the whole body.
- Do not use on or near the heart, chest or neck.
- The appliance is NOT waterproof and should NOT be submerged in water or used in the shower or bathtub.
- The unit should not be used over 30 minutes per day to avoid over-heating.
- Do not strongly press the unit on body or face.

Directions for use on body parts

FACE area

Hold the unit and move gently on face.

※ Wear a headband to keep hair away from your face to avoid hair becoming tangled in unit.

A mirror is recommended during use.



Attention

- Do NOT press unit hard to face.

OPERATION

BODY

- For Body, both Low (Face) setting and High (Body) setting are available.
- Do NOT use on one area for more than 5 minutes, to avoid over-stimulation.
- Shave excess body hair before using.
- Some white flakes of dried skin may surface on body during treatment. After use, clean applicator before storage.

Belly

Make circular movement on stomach area.

※ Maximum 5 minutes of treatment on stomach area.
※ Do not hold the unit on stomach without moving, to avoid over-stimulation.



Leg

Make circular and upper movement from foot to inner side of thigh.
At outer side, please follow the same circle method for massage.

※ Maximum 5 minutes of treatment on leg area.
※ Avoid using on boney areas.
※ Do not hold the unit on leg without moving, to avoid over-stimulation.



Hip

Make circular and upper movement from lower area to upper area.

※ Maximum 5 minutes of treatment on hip area.
※ Avoid using on boney areas.
※ Do not hold the unit on hip without moving, to avoid over-stimulation.



AFTER USAGE

Main Unit・Applicator

■ After treatment, remove applicator from main unit, clean and store properly.

■ Use dry cloth to clean main unit.

■ Wash applicators with a mild soap and water. Then, dry with clean dry cloth.

※ Main unit is NOT waterproof. Do not submerge in water.

■ Do not use harsh detergents to clean main unit.

■ Remove AC adaptor from main unit during storage.

REPAIR SERVICE

Trouble shooting during usage:

Defective Phenomenon	Defective Reasons	Countermeasures
Unit not working	● AC adaptor is not connected	Insert AC adaptor properly
	● Power Button is at OFF position	Move Power Button to FACE or BODY position
	● Applicator is stopped by foreign item(s)	Remove the foreign item(s)
	● Safety Protection system is ON	Switch off the unit and wait for 1 hour before restarting the unit.
Hot Main unit	● The unit is working for a long time	Switch off the unit and wait for 1 hour before restarting the unit.
	● Pressed down on the unit too hard	Use gentle pressure
	● Applicator is stopped by foreign item(s)	Remove the foreign items(s)

REPAIR SERVICE

Specification

Rating	12V／1A
Dimension	W85 × D85 × H134.5 mm（excluding applicator）
Unit weight	235g（excluding applicator）
Replacement Parts	AC adaptor……...1 pc Item # HBMA001 Body Roller…….....1 pc Item # HBMR002 Face Roller…….....1 pc Item # HBMR001

*NOTE: Please contact your local dealer or retail center for replacement parts.

Warranty

■ **One year warranty for manufacturing defects under normal usage.**

■ **Chargeable repair service over warranty period is available.**